

Application Instructions for Revive

Prepare:

1. Wash the surface using a pH neutral shampoo to remove excess dirt
2. Decontaminate the surface to remove any contaminants stuck to the surface

Correction:

Machine Polish the surface to remove any imperfections.

Degrease:

Remove polish residue using diluted Isopropyl Alcohol (IPA). Dilute the IPA in 30% water. For Example, in a 1L bottle add 300ml water and 700ml IPA.

Application:

1. Gently mix the Ceramic Coating bottle and apply the product on the applicator pad until fully saturated. Work in cross-hatch pattern and cover an area no bigger than 3x3ft. Spread the product with your applicator pad and pass over twice horizontally and twice vertically.
2. Put the lid back on the bottle after applying on the applicator pad to stop the product from curing inside the bottle.

TIP: Apply the product generously on the applicator pad for even application. If there are streak marks on surface when applying add a few more drops on the pad and apply again.

1. The coating starts to bond to the surface immediately. Remove excess residue immediately using at least 2 microfiber cloths. We recommend using minimum 380gsm microfiber cloths to remove residue.
2. Use the first microfiber cloth to wipe off the bulk of residue
3. The second cloth will remove any remaining residue and haze marks. Avoid using too much force when wiping off as you may scratch the surface.

Tip: If the applicator pad or microfiber cloth feels hard after a while then throw it away and use a new one otherwise, you will scratch the surface

4. Before moving onto the next panel, always inspect the area in good lighting and by checking in various angles so you haven't missed any residue.

TIP: If you have missed residue re-polish the affected panel and re-apply ceramic coating.

5. We recommend the vessel should be stationary and surface must be kept dry post application for at least 12 hours.
6. After 12 hours the vessel can be used but, we recommend avoiding manual wash for up to 7 days.

Application Video: <https://www.youtube.com/watch?v=efgxHLy2ZY8>

Layering:

1. 2 layers of Revive must be applied for 3-year warranty.
2. Wait 45 minutes between layers in summer and 60 minutes in winter.