



## **Application Instructions for Glass Coating**

1. Wash the glass with a pH neutral soap
2. Clean the surface with IPA
3. Gently mix the Ceramic Coating bottle and apply the product on the applicator pad until fully saturated and cover an area of 2x2ft. Work in cross-hatch pattern. Spread the product with your applicator pad and pass over twice horizontally and twice vertically
4. Remove excess residue after 5 minutes using a 380gsm microfiber cloths.
5. Inspect and ensure there are not haze marks
6. Apply just one layer and allow it to dry for at least 6 hours.

Application Video: <https://www.youtube.com/watch?v=oWaqc7KyVyk>