

Product Application Manual

PREPARE:

Wash the glass with a pH neutral soap.

DEGREASE:

Clean the glass surface with IPA. Dilute the IPA in 30% water. For example in a 1L bottle add 300ml water and 700ml IPA.

SUITABLE FOR:

✔ Glass

PRODUCT APPLICATION INSTRUCTIONS:

**01**

Gently shake the Glass Bottle before use.

**02**

Open the lid and apply generous amount of coating on the dry/new applicator pad.

TIP: Put the lid back on the bottle after applying on the applicator pad to stop the product from curing inside the bottle.


**03**

Work in cross-hatch pattern on small areas and make sure the coating is applied evenly.

TIP: Apply the product generously on the applicator pad for even application. If there are streak marks on surface when applying add a few more drops on the pad and apply again.

**04**

Let the product dry for 1 minute and remove excess residue using a 380gsm microfibre cloth. Inspect the surface thoroughly after wiping off to ensure there are no haze marks.

**05**

Apply just one layer of glass coating and allow it to dry for at least 6 hours.